

INSTALLATION INSTRUCTIONS

MSD 5C Ignition Control Part Number 5300

Parts Included In This Kit

- 1 - MSD 5C Ignition Control, Part No. 5300
- 4 - Self Tapping Screws
- 1 - 60" Red Jumper Wire
- 1 - Blue Wire Splice
- 1 - 45 Degree Faston Tab
- 1 - Female Faston Terminal
- 1 - Installation Instructions
- 1 - Tech Bulletin #107

MOUNTING THE MSD 5C IGNITION CONTROL

Use the four self tapping screws supplied in the parts kit to mount the Unit either in the original module location or in a location nearby. If you do not mount it in the original location, make sure that the original Chrysler module connector will reach the new mounting location. Do not mount the Ignition near the engine or exhaust manifolds.

WIRING THE CHRYSLER COMMERCIAL IGNITION MODULE

1. Remove the connector retaining screw from the original module and unplug the large, rubber connector. Plug this connector into the MSD 5C Ignition and tighten the retaining screw. See Figure 1.
2. Connect the Black wire to a good engine or chassis ground.

Figure 1

