

## V-L MODELS


## ALPHABETICAL INDEX

NAME	ZONE LOCATION	NAME	ZONE LOCATION
Air Conditioning Resistor Block .....	52C	Trunk Lamp .....	28B
Air Conditioning Compressor Clutch ..	51E	Turn Signal Indicator Lamp—Left...	34A
Alternator .....	1B	Right..	34A
Battery .....	3B	Left Fender Top .....	31D
Ballast Resistor .....	3E	Right Fender Top .....	38C
Choke Control .....	1D	Motors:	
Choke Heater .....	1E	Air Conditioning Blower Motor .....	52D
Cigarette Lighter .....	28A	Heater Blower Motor .....	52A
Circuit Breaker		Rear Window Defogger Blower Motor	5D
35 Amp—Heated Rear Window .....	9A	Starter Motor .....	6B
Distributor .....	4C	Windshield Washer Motor .....	47A
Electronic Ignition Control .....	3D	Windshield Wiper Motor (2 speed) ..	46B
Exhaust Gas Recirculation Timer ....	8B	Windshield Wiper Motor (3 speed) ..	47B
Exhaust Gas Recirculation		Radio .....	54D
Vacuum Solenoid .....	8C	Rear Window Defogger Blower	
Flashers:		Motor Resistor .....	50D
Hazard .....	30B	Relays:	
Turn Signal .....	35A	Fuel Pacer Relay .....	12D
Fusible Link .....	5B, 3A	Heated Rear Window Relay .....	10B
Gauges:		Horn Relay .....	29B
Ammeter .....	3B	Horn Selector Relay New York City ..	39B
Fuel .....	16C	Starter Relay .....	6B
Temperature .....	15C	Time Delay Relay .....	27D
Heated Rear Window .....	10C	Seat Belt—Key In Buzzer .....	19B
Heater Resistor Block .....	51A	Seat Belt Interlock Control Unit .....	19D
Horn .....	38B	Sending Units:	
New York City Horn .....	39A	Fuel .....	16D
Ignition Coil .....	5D	Temperature .....	15D
Lamps:		Speakers:	
Air Conditioning Switch Lamp .....	55D	Front .....	54B
Ash Tray Lamp .....	56D	Rear .....	56B
Back-Up-Lamp—Left .....	34D	Speed Control Servo .....	45E
Right .....	34D	Speed Generator .....	40A
Brake Warning Lamp .....	14C	Switches:	
Console Lamp .....	56E	Air Conditioning Blower Motor	
Dome Lamp .....	28C	Switch .....	51B
Gear Shift Selector Lamp .....	54C	Air Conditioning Low Pressure	
Glove Box Lamp .....	28D	Switch .....	50E
Head Lamp—Left .....	31E	Air Conditioning Vacuum Switch ...	51B
Right .....	32E	Back-up Lamp Switch:	
Heated Rear Window Indicator Lamp	11C	Automatic Transmission .....	42C
High Beam Indicator Lamp .....	30D	Manual Transmission .....	42, 43C
Ignition Switch Lamp .....	26D	Brake Warning Switch .....	14D
Instrument Cluster Lamps .....	31C, 32C	Clutch Start Switch .....	6C
License Lamp .....	34C	Defogger Switch .....	50C
Map Lamps .....	28D	Door Switch Front—Left.....	26D
Oil Pressure Indicator Lamp .....	14C	Right .....	26E
Park and Turn Signal Lamp—Left...	30C	Electronic Speed Switch .....	7C
Right..	38C	Exhaust Gas Recirculation	
Reverse Gear Indicator Lamp .....	44C	Maintenance Reminder	
Seat Belt Warning Lamp .....	18B	Lamp Switch .....	10A
Side Marker, Lamps, Front—Left....	29C	Fuel Pacer Vacuum Switch .....	10D
Right...	39C	Door Switch Rear—Left.....	56B
Side Marker Lamps, Rear—Left.....	34B	Right .....	56C
Right...	34C	Fader Switch .....	54B
Tail, Stop and Turn Signal		Foot Dimmer Switch .....	30E
Lamp—Left .....	34C	Glove Box Lamp Switch .....	28D
Right .....	34C	Hand Brake Release Switch .....	14E
Taxi Open Door Indicator Lamp ....	25D	Hazard Flasher Switch .....	31A

## ALPHABETICAL INDEX (Cont'd)

NAME	ZONE LOCATION	NAME	ZONE LOCATION
Headlight Switch .....	26C	Speed Control Switch .....	43D
Heated Rear Window Switch .....	11C	Start and Ignition Switch .....	26B
Heated Blower Switch .....	50A	Starter Interlock By Pass Switch ...	15A
Horn Switch .....	30B	Stop Lamp Switch (Std.) .....	29A
Ignition Switch .....	26B	(Speed Control)..	29A
Instrument Panel Lamp Switch .....	27C	Trunk Lamp Switch .....	28C
Key Switch .....	27D	Turn Signal Switch .....	32B
Low Oil Pressure .....	15D	Windshield Wiper Switch (2-Speed) .	46D
Map Lamp Switch .....	27E	Windshield Wiper Switch (3-Speed) .	47D
Neutral Starter Switch .....	42C	Throttle Positioner Solenoid .....	8D
New York Horn Speed Switch .....	40B	Trailer Towing .....	38D
Seat Belt Buckle Switches .....	23B-D	Voltage Limiter .....	15C
Seat Switches .....	23B-D	Voltage Regulator .....	2C

# 14-14 ELECTRICAL WIRING DIAGRAMS




PK 1 SHEET 1 OF 14


V-L Master Wiring Diagram




## -ELECTRICAL WIRING DIAGRAMS 14-15




## 14-16 ELECTRICAL WIRING DIAGRAMS-



## -ELECTRICAL WIRING DIAGRAMS 14-17




# 14-18 ELECTRICAL WIRING DIAGRAMS




V-L Master Wiring Diagram

## ELECTRICAL WIRING DIAGRAMS 14-19





## 14-20 ELECTRICAL WIRING DIAGRAMS




### V-1 Master Wiring Diagram

## 32




[illegible]







## 14-24 ELECTRICAL WIRING DIAGRAMS-



## -ELECTRICAL WIRING DIAGRAMS 14-25




## 14-26 ELECTRICAL WIRING DIAGRAMS-



### V-L Master Wiring Diagram

## 14-27

56



PK 1 SHEET 14 OF 14